# CLARKE UNIVERSITY

5340/5330/5320 IP Phone User Guide

# **FIXED FEATURE KEYS Up Arrow Key** Cancel **Down Arrow Key** Redial Speaker Hold Mute **Transfer Applications** Message

### TO MAKE AN INTERNAL CALL

1. Dial The 4 Digit Extension Number

### TO MAKE A LOCAL OR 800# CALL

- 1. Dial 9
- 2. Dial The Telephone Number

### TO MAKE AN EXTERNAL, LONG DISTANCE CALL

- 1. Dial Your 5-Digit Access Code And You Will Hear Dial Tone
- 2. Dial 1 + (Area Code) + Number

#### TO ANSWER A CALL

- 1. Lift The Handset
- Press The (Speaker) Key To Answer Over Speakerphone

## TO PLACE A CALL ON HOLD:

Press △ ← (Hold)

# TO RETRIEVE A CALL ON HOLD

- 1. Lift Handset
- 2. Press The Flashing Key

#### **CALL 2 KEY**

This Key Gives You The Capability To Make A Second Call

- 1. Put Your First Caller On Hold
- 2. Press The Call 2 Key For Dial Tone
- 3. You Can Make A 2<sup>nd</sup> Internal Or External Call

# TO TRANSFER A CALL

- 1. Press -OR- Press Trans/Conf Softkey
- Dial The Extension Number To Transfer To
- 3. Do One Of The Following:
  - To Complete The Transfer; Hang Up
  - To Announce The Transfer; Wait For An Answer, Consult, Hang Up
  - To Cancel The Transfer, Press (Cancel) -OR-The Back To Held Softkey

# TO TRANSFER A CALLER DIRECTLY TO VOICEMAIL

- 1. With Caller On The Line, Press OR- Press The Trans/Conf Softkey
- Dial 6778
- Enter The Mailbox Number To Transfer To And Hang Up

#### HOW TO PLACE A CONFERENCE CALL

- Establish Your 1st Call
- Press OR- Press The Trans/Conf Softkey
  Dial The Number Of The Next Party, wait for an answer
- 4. Press OR- Press The Conference Softkey
  - To Split A Conference And Speak Privately With The Original Party, Press The Split Softkey
  - To Alternate Between The Two Parties, Press The Trade Softkey
  - Press OR- Conference Softkey To Bring Parties Together Again

#### MUTE

- 1. Press **M** (Mute) To Temporarily Turn Off Your Phone's Handset, Headset Or Handsfree Microphone Off During A
  - If You Are On A Handsfree, Muted Call And Lift The Handset, the Mute Is Turned Off

#### **REDIAL**

To Redial The Last External Number You Manually Dialed:

1. Press 123. (Redial)

## TO CALL FORWARD YOUR PHONE

- Press (Blue Applications) Key
  Press Call Forwarding
- Enter The Number To Forward To
- Press Activate/Deactivate

### TO STORE A SPEED CALL NUMBER

- Press (Blue Applications) Key
- Press The **Settings** Softkey
- Press The Programmable Keys Softkey
- Press The Key To Program
- Press The Speed Call Softkey
- Press Edit Info
  - Use Keypad To Enter A Name, Press Save
- Press Edit Number
- 8. Dial The Number following correct dialing pattern
- Press Save
- 10. Press Close
- 11. Press Close

### TO DIAL A STORED SPEED CALL NUMBER

1. Press A Speed Call Key

## PHONE BOOK -for internal numbers only

- 1. Press The Phone Book Softkey
- 2. Enter The First Few Letters Of The Person's Last Name
- 3. Press Look Up
  - Press Call To Call The Extension
  - Press Next To Go To The Next Entry
  - Press Backup To Go To The Previous Screen
  - Press Cancel To Exit

## TO ADJUST RINGER/HANDSET/SPEAKER VOLUME

1. Press The Up And Down Arrow Key

## TO ADJUST THE DISPLAY

- Press (Blue Applications) Key
- Press Settings
- Press Contrast Or Brightness and Contrast
- Adjust The Levels
- Press Save, then press Close 5.